

Winter is over! Now it's time to adjust your thermostat from Heat to Cool



1. Press the “**SYSTEM**” button until the word “**COOL**” is flashing. Then press “**DONE**” (lower left square changes from “**SCHED**” to “**DONE**”). The “**COOL**” will stop flashing.



2. Temporarily set the temperature to lower than the current room temp (example 23°C). “**WAIT**” will show in the lower right just below “**SET TO**” temperature display.

A faint “click” will be heard and the A/C will come on. “**WAIT**” will now disappear and “**COOL ON**” will appear.

(Note: on some systems there could be a 10-15 minute delay). Once you hear the compressor fan running, you should feel cool air at the vent.



