

Program Your Thermostat Online:

Through the **peaksaver** Program, you have the ability to program your thermostat online.

To start, go to www.peaksaver.com and click on Enersource. Then click on "peaksaver Thermostat Control Centre".

You will need a User Name and Password to log on to program your thermostat online. Your **User Name** will be the **Serial Number** of your thermostat and your **Default Password** will be your **Last Name (in lower case)**. That number can be found in the battery section of the thermostat (above the battery) or on the work order the technician left at the time of installation. Allow 1-2 weeks from installation before you are established in the system for online access. You can personalize your user name and password after your initial login. For future reference, record your user name and password in the following space:

User Name: _____

Password: _____

Change Thermostat Settings Online

Through the **Thermostat Programming Portal**, it's easy!

- On the left side, under **thermostat**, click on **your serial number** to see the drop-down menu.
- Click on **Schedule** in the drop-down menu.
- Click on **Weekday** or **Saturday** or **Sunday Schedules**.
- Choose **Heating** or **Cooling** button.
- Then, simply **adjust the slide bars** to set the time and temperature.
- When complete, click on **Submit** button at the bottom of the page and you will see your thermostat accept the changes.

™ Trademark of Toronto Hydro Corporation. Used under license.
© Registered trademark of Hamilton Utilities Corporation. Used under license.



- ✓ Save Money
- ✓ Prevent Power Interruptions
- ✓ Protect the Environment

Greetings and welcome to Enersource's **peaksaver™** Program!



We have just installed your new **peaksaver** programmable thermostat. Congratulations, you are ready to begin saving on your electricity bills. Our technicians have assisted in programming your new thermostat to suit your lifestyle. We are providing this Quick Reference Guide so you can make adjustments to your thermostat settings if you need to.

We hope you will enjoy your new Honeywell Programmable Thermostat.

*If you have questions or problems, please contact the **peaksaver** Hotline at 1-866-323-0206. Our knowledgeable Customer Service Representatives are available to help..*



Change Current Time and Day

- Press **Set Clock/Day** button.
- Use **Ahead** and **Back** buttons to set time.
- Press **Set Clock/Day** button again.
- Press **Run Program** button.

Important Reminders:

There are three system modes: HEAT, COOL and OFF. These modes can be accessed by toggling the system button until the desired mode is displayed.

If no status is displayed, this indicates that the system is off.

The system will NOT automatically change from heat to cool or vice versa. To switch from heat to cool, or cool to heat, press the (insert button name).

Change Temperature/Time Settings:

COOLING/Weekday Schedule

- 1 In **Cool Mode**, press **Weekday Schedule**.
- 2 Use **Ahead** and **Back** buttons to set **wake time** for **Monday through Friday**.
- 3 Use **Warmer** and **Cooler** buttons to set **wake temperature** for **Monday through Friday**.
- 4 Repeat steps 1 through 3 for: Leaving home in the morning; Returning in the afternoon; Going to sleep at night.
- 5 Press **Run Program**. This saves your changes.

COOLING/Weekend Schedule

- 1 In **Cool Mode**, press **Weekend Schedule**.
- 2 Use **Ahead** and **Back** buttons to set **wake time** for **Saturday and Sunday**.
- 3 Use **Warmer** and **Cooler** buttons to set **wake temperature** for **Saturday and Sunday**.
- 4 Repeat steps 1 through 3 for: Leaving home in the morning; Returning in the afternoon; Going to sleep at night.
- 5 Press **Run Program**. This saves your changes.

HEATING/Weekday Schedule

- 1 In **Heat Mode**, press **Weekday Schedule**.
- 2 Use **Ahead** and **Back** buttons to set **wake time** for **Monday through Friday**.
- 3 Use **Warmer** and **Cooler** buttons to set **wake temperature** for **Monday through Friday**.
- 4 Repeat steps 1 through 3 for: Leaving home in the morning; Returning in the afternoon; Going to sleep at night.
- 5 Press **Run Program**. This saves your changes.

HEATING/Weekend Schedule

- 1 In **Heat Mode**, press **Weekend Schedule**.
- 2 Use **Ahead** and **Back** buttons to set **wake time** for **Saturday and again for Sunday**.
- 3 Use **Warmer** and **Cooler** buttons to set **wake temperature** for **Saturday and again for Sunday**.
- 4 Repeat steps 1 through 3 for: Leaving home in the morning; Returning in the afternoon; Going to sleep at night.
- 5 Press **Run Program**. This saves your changes.

To cancel any of these programs, press **CLEAR** and re-enter time and temperature desired.

To Change Your Fan Control:

Press **Fan** – When “fan” is displayed, fan is “on.” When “fan” is not displayed, fan is on “auto.”

To Change Temperature Temporarily:

Press **Warmer** or **Cooler** buttons to adjust temperature temporarily. (You may also press up or down arrows while cover is closed.) Press **Run Program** button to **end temporary change**.

Holding Temperature:

Press **Hold Temp** button. Press **Warmer** or **Cooler** buttons to adjust hold temperature. Press **Run Program** to **end temperature hold**.

To See Your Usage:

Press **Usage** button for current day. Press **Usage** button again for cumulative usage. Press **Clear** button to reset cumulative usage.

To See Your Current Temperature Setting:

Press **Present Setting** button.